


JETSTREAM ART. NMBR 2960

SERVICE MANUAL V1.0



JETSTREAM - Article number 2960



TABLE OF CONTENT

Chapter	Page
Important information	3
Function	4
Tools	5
Jetstream (art. nمبر 2960) specifications	7
Second stage exploded view	8
Second stage parts list	9
First stage 2962/2962 10 exploded view	10
First stage 2962/2962 10 parts list	11
First stage 3580 exploded view	12
First stage 3580 parts list	13
Second stage disassembly instructions	14
Second stage assembly instructions	17
Second stage adjustments	20
First stage disassembly	21
First stage assembly with cleaning instructions	27
First stage settings and adjustment	31

IMPORTANT

This manual contains preliminary servicing instructions for the Poseidon breathing regulators. It is intended to serve as a guide for repairs and servicing carried out by service technicians certified by Poseidon Diving Systems. The instructions given in this manual are based on the assumption that special tools are used and are based on our experience. The work should be done in the same order as shown in these instructions.

TYPE DESIGNATIONS

In all correspondence concerning breathing regulators, indicate the type designation and serial number. All products in this servicemanual that requires a CE-approval are of course CE-approved. CE approval represents only a minimum level of product quality and manufacturing standards. At Poseidon we put each new addition through rigorous testing procedures ourselves. This is the only proper method to ensure that your equipment will live up to our claims.

CLEANING

If corrosion or salt deposits occurs, place all metal parts in concentrated Hempocid* or 15% Hydrochloric acid for about 10 minutes. If available, all metal parts can be placed in an ultrasonic washer and cleaned in accordance with the instructions of the cleaning solution used.

Then, rinse the parts thoroughly and blow dry with air. The synthetic parts in the second stage must not be treated with solvent. They shall be cleaned in freshwater only.

**Hempocid = Acid Liquid Detergent Containing phosphoric acid (5 - 10%) and bactericid for disinfectant cleaning.*

LUBRICANTS USED

The following lubricant/oil are used:

Regulator Lubricant: Art no 8516

Oil: Silicon oil Art no 3139

SERVICE KITS

The following service kits should be used:

Second stage No. 2961, 3546, 0120-005 : Service kit no. 3549

First stage No. 2962, 3580: Service kit no. 3891

FUNCTION

POSEIDON breathing regulator is a two-stage regulator where the first stage is a diaphragm-actuated reducing valve, that reduces the primary pressure (Cylinder pressure) to approx. 123 PSI/8,5 BAR. The reduced pressure (the secondary pressure) then goes via the regulator hose to the second stage where the air supply is automatically regulated to the convenience of the diver.

The first-stage always holds the adjusted pressure above the ambient pressure which is necessary to the function of the breathing regulator. This is brought about by the outer springloaded diaphragm being in contact with the ambient pressure. It automatically responds to this pressure acting it and thereby regulates all changes in pressure.

During diving in cold water, i.e, temperatures lower than +10°C (+50°Fahrenheit), the outer spring housing of the first stage should be provided with an anti-freeze cap in order to prevent direct contact with the water. This is necessary as the considerable cooling that takes place when the primary air expands in the secondary chamber can otherwise cause ice to form and thereby prevent the springs and diaphragm from functioning.

The second-stage functions in such a way that the underpressure created in the regulator housing during each inhalation influences a diaphragm actuated valve system, which will supply the necessary air as long as the inhalation phase lasts. The automatic pressure compensation takes place in the same way as in the first stage, the outer diaphragm surface being in direct contact with ambient pressure, and the pressure on the inside of the diaphragm must correspond to ambient pressure before the diaphragm can return to its position. The diaphragm returns to its rest position and shuts off the air flowing in as soon as the inhalation phase has been broken off and the air pressure in the regulator housing has become equal to ambient pressure.








The second stage has been provided with a servo valve system for the purpose of keeping inhalation effort to a minimum.

The second stage has a built in purge button, for manual purging.

TOOLS

To service Poseidon Jetstream regulators, a mix of standard tools and specific Poseidon special tools are needed. The list below shows what specific Poseidon tools and what standard tools are needed.

Poseidon specific tools

Article nمبر.	Description	Picture
2297	O-ring remover	<p>2297 O-ring remover</p> 
3460	Regulator test	<p>3460 Regulator test</p> 
3773	Torque wrench set	<p>3773 Torque wrench set, incl 3771, 3772, 3119</p>  <p>3772 Open end insert tool 27 mm w. holder inset tool</p> <p>3771 Torque wrench 30 Nm</p> <p>3119 Bit 6 mm, length 40 mm</p>
2706	Allen key 1,5 mm	<p>2706 Allen key 1,5 mm</p> 
3605	Combination tool 1	<p>3605 Combination tool 1</p> 
3606	Combination tool 2	<p>3606 Combination tool 2</p> 
3879	Tool kit	<p>3879 Tool kit first stage</p>  <p>3717 Assembly drift A</p> <p>3757 Assembly fixture B</p>

TOOLS

Poseidon specific tools continues.

Article nمبر.	Description	Picture
8516	Regulator lubricant	
3397 10	Fixture for first stages	

Standard tools

Article nمبر.	Description	Picture
	Open end wrenches	
	Screwdriver, philips head	
	Allen keys, 4, 5, 6 mm	

JETSTREAM

Art No 2960

USA: Poseidon Odin

BREATHING REGULATOR

Primary pressure.....	Max 4351 PSI / 300 BAR
Secondary pressure.....	Max 145 PSI/ 10 BAR
Airflow.....	Approximately 1600l/min
Inhalation resistance at 115 l/min.....	Max. 40 mm of water
Exhalation resistance.....	Max. 20 mm of water

The above data apply when measuring at atmospheric pressure

FIRST STAGE VALVE

Art No 2962, 3580

Description.....	Diaphragm- actuated balanced with shear ventur boost.
Connection threads for primary pressure.....	G5/8-max 4350 PSI/300 bar accord. SS 2600/K and DIN 477/5 or yoke connection accord. SS 2603 and ANSI/CGA VI: 1987

Outlet connections:

One outlet marked R for second stage (max airflow).....	UNF 3/8" - secondary pressure
Three outlets marked LP for drysuits, buoyancy compensators, safety second stage etc.....	UNF 3/8" -secondary pressure
One outlet marked HP.....	UNF 7/16"-primary pressure
One outlet marked S has restricted airflow and therefore is intended only for dry-suit or stabjacket	Intended for first stage No. 3580 UNF 3/8" -secondary pressure
One outlet marked HP for pressure gauge.....	UNF 7/16" -primary pressure

SECOND STAGE VALVE

Art No 2961, 3546, 0120-005, 0120-006

Description.....	Upstream diaphragm actuated, servo assisted with safety relief, fixed ejector system. Purge button for clearing. Sensitivity switch for added control.
------------------	--

REGULATOR HOSE WITH INTEGRAL SAFETY VALVE

Art No 2946, 4680-70

Length.....	28 inch / 70 cm
Release pressure	Approx. 247 PSI / 17 bar

TIGHTENING TORQUE

Primary connection	20 - 22 lbf.ft / 28 - 30 Nm
Valve cover	20 - 22 lbf.ft / 28 - 30 Nm
Connections marked R-LP-HP.....	6 lbf.ft / 8 Nm
Balanced housing	7 lbf.ft / 10 Nm

ANTI-FREEZE PROTECTION

Art No 1286


Type	Rubber cap
------------	------------

Parts list: 2nd stage 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080

Art. Nbr.	Description
1	0010-353 (2782) O-ring
2	4680-70 LP hose with built in OPV*, 70 cm / 27,5 inch
	4680-90 LP hose with built in OPV*, 90 cm / 35,4 inch
3	3088 Low pressure valve, complete
4	0010-355 (2856) O-ring
5	2857 LP valve house
6	0010-028 (1145) O-ring
7	3440 Valve insert
8	0012-007 (1233) O-ring
9	2947 Valve house nut
10	2875 Stop screw M3x4
11	2787 Rubber plate
12	0015-019 (2876) O-ring
13	2839 Valve tube, Jetstream
14	0010-002 (1896) O-ring
15	2786 Servo valve Jetstream, complete
16	4532 Mouthpiece
17	1167 Locking strap
18	3122 Housing with switch, Black
	3132 Housing with switch, Yellow
	0005-170 Housing with switch, Blue
	0005-171 Housing with switch, Red
	0005-172 Housing with switch, Grey
19	2578 Membrane with washer
20	2707 Cover 2nd stage Jetstream, Black
	2989 Cover 2nd stage Jetstream, Yellow
	0000-775 Cover 2nd stage Jetstream, Blue
	0000-776 Cover 2nd stage Jetstream, Red
	0000-777 Cover 2nd stage Jetstream, Grey
21	2851 Screw M2x8
22	2853 Purge button
23	2961 05 LP Valve Jetstream, Black
	3546 05 LP Valve Jetstream, Yellow
	0005-165 LP Valve Jetstream, Blue
	0005-166 LP Valve Jetstream, Red
	0005-167 LP Valve Jetstream, Grey
24	2711 Switch
25	0010-018 (1851) O-ring
26	3120 Demand valve housing, Black
	3130 Demand valve housing, Yellow
	0000-771 Demand valve housing, Blue
	0000-772 Demand valve housing, Red
	0000-773 Demand valve housing, Grey
27	2794 Lock washer
28	2712 Diaphragm cam

*Only hose with built in OPV can be used.


Exploded view: 1st stage 2962 / 2962 10 (Yoke)



Parts list: 1st stage 2962 / 2962 10 (Yoke)

Art. Nbr.	Description	Art. Nbr.	Description		
1	3417	Adjusting screw	41	1227	Knob**
2	2802	Secondary spring	42	1841	Yoke**
3	3418	Inner secondary spring	43*	2778	Locking strap
4	2814	Cover for valve housing	44*	1287	Anti freeze cap
5	3419	Upper diaphragm centre	45*	1286	Anti freeze cap with locking strap
6	1189	Diaphragm			
7	2816	Diaphragm centre lower			*Accessories
8	2817	Valve needle			**No longer available as a spare part
9	0010-353	(2782) O-ring x 4			
10	2679	Blanking plug UNF 3/8" x 3			
11	3258	Valve housing, for 3257**			
12	0010-354	(2918) O-ring			
13	2680	Blanking plug UNF 7/16"			
14	0010-009	(1156) O-ring			
15	2803	Valve seat			
16	2820	Valve piston			
17	2821	Spacing sleeve			
18	0012-126	(1368) O-ring			
19	2822	Support washer			
20	0010-015	(2809) O-ring			
21	2823	Balanced housing**			
22	3388	Spring guidance			
23	3387	Pressure spring			
24	0010-010	(1562) O-ring			
25	2807	Blanking plug G 1/8"***			
26	2402	Protective cap for 1st stage			
27	3096	Locking screw			
28	0012-028	(1007) O-ring			
29	0010-006	(2656) O-ring			
30	1377	Cup filter			
31	2827	Connection stem, Cyklon			
32	0010-013	(1839) O-ring			
33	2828	Connection wheel G5/8"			
34	2966	Reconstruction set Jetstream (27-33)			
35	3472	Connection, Yoke			
36	2922	Yoke handle (New model)			
37	3473	A-clamp, Yoke.			
38	2277	1st stage cover, Yoke			
39	1183	Locking screw**			
40	2825	Connection**			

Exploded view: 1st stage 3580




Parts list: 1st stage 3580

Art. Nbr.	Description	Art. Nbr.	Description		
1	3417	Adjusting screw	41*	3293	Banjo housing
2	2802	Secondary spring	42*	1095	Throttle screw
3	3418	Inner secondary spring	43*	3292	Banjo screw
4	2814	Cover for valve housing	44*	3291	Swivel coupling 30 bar, UNF 7/16". Incl. 9, 38, 40-43
5	3419	Upper diaphragm centre			
6	1189	Diaphragm			
7	2816	Diaphragm centre lower			
8	2817	Valve needle			
9	0010-353	(2782) O-ring x 4			
10	2679	Blanking plug UNF 3/8" x 4			
11	3581	Valve housing, for 3585**			
12	3587	Restrictor screw for 1st stage 3585 Cyklon 5000			
13	3024	Blanking plug M7x1			
14	0010-009	(1156) O-ring			
15	2803	Valve seat			
16	2820	Valve piston			
17	2821	Spacing sleeve			
18	0012-126	(1368) O-ring			
19	2822	Support washer			
20	0010-015	(2809) O-ring			
21	2823	Balanced housing**			
22	3388	Spring guidance			
23	3387	Pressure spring			
24	0010-010	(1562) O-ring			
25	2807	Blanking plug G 1/8"***			
26	2402	Protective cap for 1st stage			
27	3096	Locking screw			
28	0012-028	(1007) O-ring			
29	0010-006	(2656) O-ring			
30	1377	Cup filter			
31	2827	Connection stem, Cyklon			
32	0010-013	(1839) O-ring			
33	2828	Connection wheel G5/8"			
34	2966	Reconstruction set Jetstream (27-33)			
35	2787	Locking strap*			
36	1287	Anti freeze cap			
37	1286	Anti freeze cap incl. 35-36*			
38	0010-354	(2918) O-ring			
39	2680	Blanking plug UNF 7/16"			
40	3294*	Spacer			

*Accessories

**No longer available as a spare part

DISASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080



Disconnect the low pressure hose from the second stage.

Remove the low pressure valve from the housing (15) with a screwdriver. Make sure the servo valve needle is not bent. Be sure to hold the low pressure valve carefully, to avoid dropping it (see figure).

Cut off the locking strap (17) with cutting pliers. Remove the mouth piece (16).

Unscrew the 4 screws (26) with a 3.5 mm screwdriver.

Remove the cover (25) and the diaphragm (24).

Remove the purge button (27).


IMPORTANT

The switch should not be removed if it is undamaged.

Removal:

- Pull out the diaphragm cam (22).
- Cut off the switch (18) with a pair of cutting pliers close to the locking washer (21). Remove the switch.
- Remove the o-ring (19).


DISASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080




Remove the servo valve (14).

Unscrew the stop screw (9) and remove the valve tube (12). Remove the o-rings (11) (13) with an o-ring remover. Make sure the sealing surfaces are not damaged.


Remove the rubber plate (10).




Place the valve housing in the tool. Unscrew the valve housing (4) with a special spanner.




Remove the o-ring (7) with an oring remover. Make sure the sealing surfaces are not damaged.



Remove the valve insert.



Remove the o-rings (5) (3) with an o-ring remover. Make sure the sealing surfaces are not damaged.



Sealing surfaces


DISASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080

When servicing the 2nd stage all o-rings, including the one in the low pressure hose, should be replaced.

CLEANING:

If corrosion or salt deposits occurs, place all metal parts – in an ultrasonic washer or in a 15% Hydrochloric acid solution for about 10 minutes. Then, rinse the parts thoroughly and blow dry with air. The synthetic parts in the second stage must not be treated with solvent. They shall be cleaned in freshwater only.


BEFORE ASSEMBLY CHECK THE FOLLOWING:




Diaphragm (24). Check that the sealing surface of the diaphragm is even. Also check that there are no holes in the diaphragm and that the diaphragm washer is properly fixed in position.



The mouth-piece (16). Make sure there are no cracks.



The purge button (27). Make sure there are no cracks. Check to make sure the spring is undamaged.




Servo valve (14). Check to make sure that the valve bar is not bent.


The switch: Put the switch into - and + position. It should be moved rather slowly, control the position of the diaphragm and that it is properly tightened.

ASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080


Assembly:




Mount the o-rings (5,3) on the valve housing (4). Use the tools. (See diagram.)



Install the valve insert (6) in the valve housing (4).




Place the o-ring (7) in the groove of the valve insert (6). Lubricate the thread. Install the valve housing nut (8).




Place the valve housing in the handle. Tighten with a tool. (See diagram.)

ASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080




Install the o-rings (11,13) on the valve tube (12). Grease the threads and the o-rings.




Screw in the valve tube (12) until about 2 mm space remains as illustrated.

Install the rubber plate (10). Screw in the set screw (9). Do not tighten up.

Screw the servo valve (14) on to valve tube (12). Tighten up. Be careful not to bend the valve needle.



Test the low pressure valve for leakage. See chapter: Final adjustment.




SWITCH

Fit in o-ring (19) and lubricate it.

Fit in the switch with the narrow part against the - minus sign on the second stage valve. See diagram.




Install the locking washer (21) on the switch (18). Press it on a drift. Tighten the locking washer so that there is sufficient resistance when setting the switch.




Fix the diaphragm cam (22) upon the switch (18). Set switch at - (minus), press the diaphragm cam into correct position per the diagram.

The distance from the top of the diaphragm cam to the housing should be 2 mm, concerns diaphragm of silicone rubber, see diagram.



Carefully push diaphragm cam into the right position. Note the cam should be pushed slowly on to the switch so that the switch is not moved.

ASSEMBLY - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080



Fit the purge button in the cover (25) for the second stage. Make sure that the spring is undamaged.

Position the diaphragm (24) with the diaphragm washer facing down wards and the hole positioned as illustrated.

Position the cover (25) for the second stage according to the adjacent illustration. Lubricate the screw and tighten (27) with a screwdriver.

Install the mouth piece (16) and the locking strap (17). Tighten up and cut off with plastic band pliers.

Checking the second stage for leaks: Place the mouth piece against your lips and cover the low pressure hose connection with your thumb and inhale lightly. This will create a partial vacuum inside the second stage. If the pressure does not equalize in 5 second stage leaks. See chapter fault detecting.

LOW PRESSURE HOSE WITH SAFETY VALVE

Check the hose for cracks or other defects. Check the sealing surfaces and threads. Install the o-ring (1) and lubricate it.

Install the hose in the outlet of the first stage valve marked R (important for the regulators performance). Tighten with 13 mm open- end wrench.

ADJUSTMENT - 2nd STAGE 2961, 3546, 0120-005, 0120-006, 0120-020, 0120-030, 0120-080

Second stage valve: Tightness testing of the low pressure valve with servo valve.

Close the HP valve and purge fully by means of the purge button.

Remove the low pressure valve from the second stage housing.

Place the low pressure valve in the test fixture and screw on the hose.

Open the LP valve, push the servo valve's needle carefully, and purge a few times. Immerse the valve below the surface of the water in a special water tank and check to make sure that the valve is absolutely tight.

Move the low pressure valve to the second stage valve and fit the low pressure valve's outlet to the guide fitting in the second stage housing. Make sure that the valve is inserted straight to prevent the servo valve from becoming damaged.

Lubricate the external thread on the second stage housing and the end of the hose nipple. Screw on the low pressure hose.

Adjustment of the inhalation resistance:

Open the HP valve.

Connect the oval connecting pipe on the inhalation resistance gauge to the mouth-piece on the regulator.

Test-breathe very carefully. Check the reading of the gauge needle, which should rise to 35-40 mm/vp and then move back. The turning point reading equals the inhalation resistance. If the reading is too low, screw the valve tube away from the diaphragm as shown in the illustration. If the reading is too high, screw the valve tube towards the diaphragm.

Tighten up the stop screw.


Checking the purge button:

Press the purge button. The second stage valve should now provide a generous supply of air.


Cover the mouth-piece and press the purge button. The second stage valve should then supply a reduced flow air.

Depressurize the regulator.

Close the HP valve.



DISASSEMBLY - 1st STAGE 2962, 3580





Disconnect the low pressure hose from the first stage valve using a 13 mm open end wrench.

Remove the o-ring from the low pressure hose. Make sure the sealing surfaces are not damaged.

Removal:


Place the first stage valve with the secondary side facing upwards in a fixture/vise. If you are using a vise, make sure not to damage the first stage housing.




Remove the pressure adjusting screw (1) with a 6 mm Allen wrench and remove the spring (2) and (3).

Remove the cover (4) using a 27 mm crowsfoot and the upper diaphragm centre (5).

Remove the diaphragm (6). Make sure the sealing surface is not damaged. Remove the lower diaphragm centre (7) and the valve needle (8).




DISASSEMBLY - 1st STAGE 2962, 3580




BALANCE HOUSING

Removal:


Place the first-stage valve with the balanced housing facing upwards.




Steady the balance housing with a special wrench. Then remove the blind screw (25) with a 5 mm Allen wrench. Remove the o-ring (24) with an o-ring remover. Remove the balance housing (21) with the special wrench.




Remove the spring (23) and the spring guidance (22).



Remove the valve piston (16) and the spacing sleeve (17). Remove the o-ring (18) with an o-ring remover. Remove the washer (19) and the o-ring (20). Use an o-ring remover for this also. Make sure the sealing surfaces are not damaged.




DISASSEMBLY - 1st STAGE 2962, 3580





Remove the protective cap (26).

Remove the locking screw (27) with a 6 mm Allen wrench. Remove the o-ring (28) and the cupfilter (30).


Place the first stage in the fixture. Remove the connecting (31) with a 6 mm Allen wrench.




Remove the wheel (33) and the o-ring (32) with an o-ring remover. Make sure the sealing surfaces are not damaged.



DISASSEMBLY - 1st STAGE 2962, 3580





Remove the valve seat (15) with a valve seat remover.





Remove the o-ring (14) with an o-ring remover. Make sure the sealing surface is not damaged.

Remove the valve housing from the fixture.



Remove the blind screw (10 and 13) with a 5 mm Allen wrench. Remove the o-rings (9 and 12) with an o-ring remover. Make sure the sealing surfaces are not damaged.




Sealing surfaces



DISASSEMBLY - 1st STAGE 2962, 3580

When servicing the regulator the following parts should be replaced:

1. All o-rings
2. Diaphragm
3. Cup filter
4. Valve seat
5. Washer



CLEANING


If corrosion or salt deposits occurs, place all metal parts in an ultra-sonic washer or in a 15% Hydrochloric acid solution for about 10 minutes. Then, rinse the parts thoroughly and blow dry with air. The synthetic parts in the second stage must not be treated with solvent. They shall be cleaned in freshwater only.

CHECKING

Check the following parts very carefully. Replace even if only slightly damaged.

- Valve needle (8). Check to make sure that the needle is straight.
- The blind screws (10 and 13). Check to make sure the sealing surfaces are undamaged. Also check that the threads are not damaged.
- The valve housing (11) Check to make sure the threads and also the sealing surfaces for the o-rings are undamaged.

DISASSEMBLY - 1st STAGE 3580




- The connections (29,31 or 33). Check to make sure the sealing surfaces for the o-rings are undamaged.


- 5. Balanced housing (21). Check to make sure the threads and also the sealing surfaces for the o-rings are undamaged.

ASSEMBLY - 1st STAGE 2962, 3580


ASSEMBLY




Install the o-rings (9) and (12) on the blind screws (10) and (13). Lubricate through the outlets.




Screw in the blind screws in the LP- HP outlets. Use a 5 mm Allen wrench and tighten up by hand.




Install the o-ring (14) on the valve seat (15) and the install the valve seat with a seat drift. Press the drift diagonally as shown in the diagram and the "rock" it to the vertical while pressing down. The seat and o-ring should pop into place. This procedure avoids damage to the o-ring from the high pressure supply outlet.



ASSEMBLY - 1st STAGE 2962, 3580




Install the o-ring (31) on the connection (30). Lubricate the o-ring and the thread.



Install the wheel (33) on the connection.


Screw the wheel connection assembly into, the valve housing assembly with a 6 mm Allen wrench.



Place the valve housing (11) in a fixture. Tighten with a torque wrench to 28 - 30 Nm (20-22 lbf.ft.).


IMPORTANT! Use bits No 3119 (L = 40 mm). Put o-ring (29) on the cup type filter (30). Install these and o-ring (28) and the locking screw (27) in connection (31). Tighten with a Allen wrench 6 mm.

ASSEMBLY - 1st STAGE 2962, 3580




Install the o-ring (24) on the blind screw G 1/8" (25).


Grease the inside of balanced housing (21).



Install the spring guide (22) and the spring (23). Screw in the blind screw (11) with a 5 mm Allen wrench. The blind screw should be tightened while the balanced housing is held in the valve housing.




Install the o-ring (20) at the balanced housing .




Install the washer (19) and the o-ring (18). Grease the inside of o-ring and the washer. Install the spacing sleeve (17) and the valve piston (16).



Install the balanced housing (21) in the valve housing (11) and tighten the blind screw with a 5 mm Allen wrench.



ASSEMBLY - 1st STAGE 2962, 3580



Turn the valve housing with the secondary side upwards.

Install the valve needle (8). At previous models the needle was beveled in one edge. The bevel should in these cases be pointed downwards.

Install the lower diaphragm centre (7) and the diaphragm (6), which must be pushed into the groove in the valve housing. Check to make sure that this is correctly installed by pressing it downwards. It should move approximately 2 mm (1/16").

Install the upper diaphragm centre (5).

Install the cover (4) and tighten with a torque wrench to 28 - 30 Nm. (20-22 lbf.ft).

Install the spring (2) and (3), lubricate both ends of the spring and the thread on pressure adjusting screw, and tighten 5 turns with a 6 mm Allen wrench.

Assembly completed.

ADJUSTMENTS AND SETTINGS - 1st STAGE 2962, 3580

Preparing the first stage for adjustment

Before starting the process of setting the intermediate pressure of the first stage, it's recommended that you do the following steps.

- Un-screw the adjustment screw to the point where there is no tension on the adjustment spring.
- Connect the first stage to a regulator test box.
- Open the left hand side valve (Low Pressure) on the regulator test box and check for leaks. The intermediate pressure gauge should show 0 bar/psi intermediate pressure.
- If no leaks are found, open the right hand side valve (high pressure) and check the intermediate pressure gauge. It should still show 0 bar/psi intermediate pressure.
- Allow the first stage to sit, under high pressure, for one minute.
- Then start turning the adjustment screw, so that there is an intermediate pressure shown on the intermediate pressure gauge.
- Turn off both valves on the regulator test box.
- Depressurize the regulator.

You are now ready for the next step: Setting the intermediate pressure.

Setting the intermediate pressure

Connect the regulator to the test equipment.

Connect the regulator test low pressure gauge hose to one of the low pressure outlets.

Open the LP valve (=20 bar/290 psi).

Set the secondary pressure at 10 bar, and intermittently purge the second stage by means of the purge button. NOTE that the second stage valve must be fully tight during this test. When the pressure gauge needle stops at the preset pressure, a maximum rise in pressure of 1 bar is allowed before the needle finally stops. If the needle continues to move to a higher pressure reading there is a fault in the seal between the valve seat and piston or the O-ring.

Close the LP valve, and open the HP valve (=200/300 bar). Purge intermittently with the purge button and adjust the pressure to 8.5 bar/ 123 psi. Tighten up the stop screw on the cover.

Close the HP valve and purge it fully.

The first stage intermediate pressure has now been set.

Intermediate pressure quick reference table.

1st stage model	TANK PRESSURE		Notes
	20 bar	M.T.P*	
2962	+1,5 bar (22 psi) / -1,0 bar/ (14,5 psi)	8,5 bar / 123 psi	Balanced 1st stage
3580	+1,5 bar (22 psi) / -1,0 bar/ (14,5 psi)	8,5 bar / 123 psi	Balanced 1st stage

* Max Tank Pressure = Full tank

Issue 2.0

Copyright © Poseidon Diving Systems AB 2005 - 2013

All rights reserved. No parts of this book may be reproduced in any form whatsoever without written permission of the publisher.

Service manual Jetstream Art. Nnbr. 2960.